


SSH Ipsec client behind a NAT doing IPsec Pass through to a RF550VPN

The figure is an example to setup VPN connection between two different stations (Station A & Station B).



RF550VPN Settings:

Connection Name: IPsec pass through

Enable Enable UID (Unique Identifier String)

Local IPsec Identifier: 204.26.122.50

Remote IPsec Identifier: 10.10.10.2

Remote IP Network: 10.10.10.2

Remote IP Subnet Mask: 255.255.255.255

Remote Gateway IP: 204.26.122.103

Secure Association: enable IKE

Perfect Forward Secure: Enable

Encryption Protocol: 3DES

PreShared Key: 12345678